


T-Mobile Franklin T10 Mobile Hotspot




1. Hold the Power button for 3 seconds until “WELCOME” shows on the OLED display.
2. Wait until it shows the T-Mobile display screen (see image below).
3. Be sure the device you want to connect (phone, laptop/computer, tablet, etc.) has its Wi-fi turned on.
4. On the device you want to connect, open the Wi-fi settings. The default Wi-Fi name will be “WILLIAM JEANES LIBRARY #.” Select it.
5. On the Hotspot, press the Power/Menu button two times for the randomly generated password. (Please note this info is not printed on the back cover.) Enter this password on your device.
6. Your device should now be connected to the Internet. You can connect up to 15 devices by following steps 3-5 for each device. (Speed will decrease with additional devices.)



Button Operation:

	Operations	Actions
	Turn On	Press and hold the button for 3 seconds.
	Turn Off	Press and hold the button until “Goodbye” message appears.
	Display Wake-Up	When the display is off (sleep mode), the first quick press of the button wakes up the display.
	Info Display	When the display is on, press the button quickly to go through the device menu and information.

LED Indicator:







	Colors	Charging Status
	Off	Power off.
	Solid	Power off and connected to a charger.
	Blinking	Power on / Operating normally

For assistance:

William Jeanes Memorial Library
610-828-0441
jeanesinfo@mclinc.org

Display screen:



Icons	Description
	4 level signal strength indicators. More bars indicate a stronger signal.
	Networks icon appears depends on which networks connected. (LTE / 3G / Roaming)
	Appears when data is being transmitted between the mobile network and your hotspot.
	Shows the number of connected devices. (1~14 and Max).
	Appears when you have unread messages.
	The bar inside the battery indicates the battery level. When battery power is low, the battery outline blinks.